Name	Sudoku Lucas Gen 2 8S	Sudoku Lucas Gen 2 10S	Sudoku Lucas Gen 2 10SH	Sudoku Lucas Gen 2 12S	Sudoku Lucas Gen 2 12SH	Sudoku Lucas Gen 2 14S	Sudoku Lucas Gen 2 14SH	Sudoku Lucas Gen 2 14SH PRO	Sudoku Lunar 11R	Sudoku Lexus 9Pro	Sudoku Lexus 10Pro	Sudoku Lexus extreme 12pro	Sudoku Lexus extreme 14pro	Sudoku Home Practice HP8 gen2	Sudoku Home Practice HP8 gen2
Model															
Module	Sudoku Lucas Gen 2	Sudoku Lucas Gen 2	Sudoku Lucas Gen 2	Sudoku Lucas Gen 2	Sudoku Lucas Gen 2	Sudoku Lucas Gen 2	Sudoku Lucas Gen 2	Sudoku Lucas Gen 2	- Sudoku Lexus - Roland td17	- Sudoku Lexus - alesis strike pro - Roland td17	- Sudoku Lexus - alesis strike pro - Roland td17	- Sudoku Lexus - alesis strike pro - Roland td17	- Sudoku Lexus - alesis strike pro - Roland td17	Home Practice	Home Practice
Kick 1	10” mesh kick	10” mesh kick	10” mesh kick	10” mesh kick	10” mesh kick	10” mesh kick	10” mesh kick	20” mesh kick	10” mesh kick	20” mesh kick	20” mesh kick	20” mesh kick	20” mesh kick	8” Bass Drum Pad	8” Bass Drum Pad
Kick 2	—	—	—	—	—	—	—	—	—	—	—	—	20” mesh kick	—	—
Snare	10” mesh pad	10” mesh pad	10” mesh pad	10” mesh pad	10” mesh pad	10” mesh pad	10” mesh pad	10” mesh pad	10” mesh pad	12” mesh pad	12” mesh pad	12” mesh pad	12” mesh pad	8” snare pad	8” snare pad
Hihat	Hihat controller pedal	Hihat controller pedal	Stand Alone Hihat Stand	Hihat controller pedal	Stand Alone Hihat Stand	Hihat controller pedal	Stand Alone Hihat Stand	Stand Alone Hihat Stand	Hihat controller pedal	Stand Alone Hihat Stand	Stand Alone Hihat Stand	Stand Alone Hihat Stand	Stand Alone Hihat Stand	- with/without hihat stand - Single/Double pedal	- with/without hihat stand - Single/Double pedal
Tom 1	8” mesh pad (dual zone)	8” mesh pad (dual zone)	8” mesh pad (dual zone)	8” mesh pad (dual zone)	8” mesh pad (dual zone)	8” mesh pad (dual zone)	8” mesh pad (dual zone)	8” mesh pad (dual zone)	8” mesh pad (dual zone)	10” free floating wood mesh tom	10” free floating wood mesh tom	8” mesh pad (dual zone)	8” mesh pad (dual zone)	8” rubber pad	8” rubber pad
Tom 2	8” mesh pad (dual zone)	8” mesh pad (dual zone)	8” mesh pad (dual zone)	8” mesh pad (dual zone)	8” mesh pad (dual zone)	8” mesh pad (dual zone)	8” mesh pad (dual zone)	8” mesh pad (dual zone)	8” mesh pad (dual zone)	10” free floating wood mesh tom	10” free floating wood mesh tom	10” free floating wood mesh tom	10” free floating wood mesh tom	8” rubber pad	8” rubber pad
Tom 3	8” mesh pad (dual zone)	8” mesh pad (dual zone)	8” mesh pad (dual zone)	8” mesh pad (dual zone)	8” mesh pad (dual zone)	8” mesh pad (dual zone)	8” mesh pad (dual zone)	8” mesh pad (dual zone)	10” mesh pad (dual zone)	10” free floating wood mesh tom	10” free floating wood mesh tom	10” free floating wood mesh tom	10” free floating wood mesh tom	8” rubber pad	8” rubber pad
Tom 4	—	—	—	8” mesh pad (dual zone)	8” mesh pad (dual zone)	8” mesh pad (dual zone)	8” mesh pad (dual zone)	8” mesh pad (dual zone)	10” mesh pad (dual zone)	—	10” free floating wood mesh tom	10” free floating wood mesh tom	10” free floating wood mesh tom	—	—
Tom 5	—	—	—	—	—	—	—	—	—	—	—	—	10” free floating wood mesh tom	—	—
Hihat cymbal	12”	12”	12”	12”	12”	12”	12”	12”	12”	12”	12”	12”	12”	12”	12”
Crash 1	12” 2 zone	12” 2 zone	12” 2 zone	12” 2 zone	12” 2 zone	12” 2 zone	12” 2 zone	12” 2 zone	12” 2 zone	14” 2 zone	14” 2 zone	12” 2 zone	12” 2 zone	12”	12”
Crash 2	—	12” 2 zone	12” 2 zone	12” 2 zone	12” 2 zone	12” 2 zone	12” 2 zone	12” 2 zone	12” 2 zone	14” 2 zone	14” 2 zone	14” 2 zone	14” 2 zone		12”
Crash 3	—	14” 2 zone	14” 2 zone	12” 2 zone	12” 2 zone	12” 2 zone	12” 2 zone	12” 2 zone	12” Effect	—	—	14” 2 zone	14” 2 zone	—	—
Crash 4	—	—	—	14” 2 zone	14” 2 zone	14” 2 zone	14” 2 zone	14” 2 zone	—	—	—	15.5/16” 2 zone	15.5/16” 2 zone	—	—
Crash 5	—	—	—	—	—	14” 2 zone	14” 2 zone	14” 2 zone	—	—	—	—	—	—	—
China 1	—	—	—	—	—	15.5/16” 2 zone	15.5/16” 2 zone	15.5/16” 2 zone	—	—	—	—	—	—	—
Stand	—	—	—	Cymbal Stand	Cymbal Stand	Cymbal Stand	Cymbal Stand	Cymbal Stand	—	—	—	—	—	—	—
Ride	12” Full cover 3 zone	15.5/16” Full cover 3 zone	15.5/16” Full cover 3 zone	15.5/16” Full cover 3 zone	15.5/16” Full cover 3 zone	15.5/16” Full cover 3 zone	15.5/16” Full cover 3 zone	15.5/16” Full cover 3 zone	15.5/16” Full cover 3 zone	15.5/16” Full cover 3 zone	15.5/16” Full cover 3 zone	15.5/16” Full cover 3 zone	15.5/16” Full cover 3 zone	12”	12”
Bluetooth	Dual audio & MIDI	Dual audio & MIDI	Dual audio & MIDI	Dual audio & MIDI	Dual audio & MIDI	Dual audio & MIDI	Dual audio & MIDI	Dual audio & MIDI	Dual audio & MIDI	Dual audio & MIDI	Dual audio & MIDI	Dual audio & MIDI	Dual audio & MIDI	USB MIDI	USB MIDI
Midi	USB	USB	USB	USB	USB	USB	USB	USB	USB	USB	USB	USB	USB	—	—
Advanced setting	Sensitive, Retrig Thresh, X-talk, Velocity curve	Sensitive, Retrig Thresh, X-talk, Velocity curve	Sensitive, Retrig Thresh, X-talk, Velocity curve	Sensitive, Retrig Thresh, X-talk, Velocity curve	Sensitive, Retrig Thresh, X-talk, Velocity curve	Sensitive, Retrig Thresh, X-talk, Velocity curve	Sensitive, Retrig Thresh, X-talk, Velocity curve	Sensitive, Retrig Thresh, X-talk, Velocity curve	Sensitive, Retrig Thresh, X-talk, Velocity curve	Sensitive, Retrig Thresh, X-talk, Velocity curve	Sensitive, Retrig Thresh, X-talk, Velocity curve	Sensitive, Retrig Thresh, X-talk, Velocity curve	Sensitive, Retrig Thresh, X-talk, Velocity curve	—	—